	<b>Instructions for Erection &amp; Operation</b>	Document No. <b>IS 2679</b>
<b>Outdoor Transformer Bushing 24 kV to 245 kV Series PSR</b>		Revision: <b>A</b> Date: <b>22.11.22</b> Page: 1 of 19 Appendices: 5

## Contents

<b>1</b>	<b>GENERAL DESIGN</b>	<b>2</b>
<b>2</b>	<b>PACKING, UNPACKING, HANDLING</b>	<b>3</b>
2.1	Bushing supply conditions	3
2.2	Transport case	4
2.3	Lifting and handling	4
2.4	Repacking for further transportation	4
<b>3</b>	<b>STORAGE</b>	<b>4</b>
3.1	Proceedings after inexpert storage	5
<b>4</b>	<b>INSTALLATION AND COMMISSIONING</b>	<b>6</b>
4.1	Preparation before assembling	6
4.2	Conductor and terminal	6
4.3	Assembling of the bushing onto the transformer	7
4.4	De-aeration and resting time	7
4.5	Evacuation of the transformer	7
4.6	Measuring tap	7
<b>5</b>	<b>MAINTENANCE, REPAIR, DISPOSAL</b>	<b>8</b>
5.1	Maintenance	8
5.2	Spare parts	8
5.3	Repair	8
5.4	Safety information	9
5.5	Disposal	9
5.6	NAME PLATE	9
<b>6</b>	<b>APPENDIX</b>	<b>10-19</b>

All rights reserved for this document and the presented objects. Duplication, publication to third parties or utilisation beyond the agreed purpose without the manufacturer written agreement is not permitted.

Originated from: IS2679	Replaced by: IS2679-A	Amendments: A: Added the shock indicator
Written by: M. Campana	Approved by: G. Scuderi	



## 1 General design

**(See drawing 6.1 in appendix)**

The main insulation of the bushing consists of an insulation core made of resin impregnated paper with aluminium layers for capacitive grading (7).

For installation on the transformer the main flange is mounted oil-tight on the insulation (3).

The insulation core against environmental pollution, humidity, or ultraviolet radiation, it is covered with a Composite insulator (2).

In the centre of the bushing a cable bolt to braze in a draw lead or a removable conductor is installed according to the order (item 1 of drawing 6.3).

A sealing O-rings is installed below the Top terminal of the bushing to seal up the transformer compartment from atmospheric environment.

Since the bushing is completely dry, it can be transported, stored, and installed in any position.

For measuring capacitance and dissipation factor  $\tan \delta$ , a self-grounding measuring tap is provided on the main flange (4).

Be aware, that the connection to the bushings top terminal must not be of rigid type. To avoid vibration and dilatation being transmitted from the transformer to the connected line it is essential to have a flexible joint in-between.



## 2 Packing, Unpacking, Handling

### 2.1 Bushing supply conditions

For protection against damage, the bushings are dispatched in wooden transport cases. The cable bolt/stem conductor is assembled within the bushing. The complete bushing is protected against humidity by a vacuumed and sealed barrier bag containing a drying cartridge.

Before proceeding with the unpacking operation, it is necessary to perform the following controls:

- Check the wooden crate status.
- Check the external visual shock indicator(s) (**Figure 1**)
- Open the crate and inspect packaging and goods inside.
- Check the status of the terminals and the relevant accessories.



Figure 1 – Visual external shock indicator

The activation of the shock indicator (RED coloured) or any damage of the crate and of the goods inside must be reported to GE Grid Solutions SpA - RPV.



## 2.2 Transport case

Gross and net weight and dimensions are given in the dispatch notice.

## 2.3 Lifting and handling

### See 6.2 in the Appendix

#### - Removing the bushing from the shipping box

Small types can be taken out by hand; larger types require ropes and lifting gear.

#### - Bringing the bushing into vertical position

The easiest way is by means of two ropes. One end of the rope is enlaced just below the top or fixed with an eyebolt to the top terminal; the other end is fixed with a hook in the eyebolts at the main flange. This eyebolt can be screwed into the designated threading in the flange. The bushing is first lifted horizontal with both lifting gears together. Then, the bottom part or flange side can be lowered down.

#### CAUTION

The lifting gear enlaced around the sheds must **not** have sharp edges and should be of a soft type like textile noose to avoid damage on the insulator. The bushing must not touch the floor while lowering down because the insulation body might get damaged. The bushing should not be turned into vertical position with only one rope since the bushing could slip through the noose and fall down.

## 2.4 Repacking for further transportation

It is necessary to ensure that the quality of packing, the protection against humidity and damage, is as good as on delivery.

## 3 Storage

Concerning the storage of the bushing, the location (outdoor, rain protected or indoor) and the duration of storage (short, medium, or long term) must be considered. If necessary, a storage container can be ordered to the manufacturer.

#### CAUTION

In general, the moisture protection of the bushing must be mounted at any time.

	<b>Outdoor, protected from rain</b>	<b>Indoor</b>
<b>Short term</b> max.1 year	In original transportation box, covered with plastic. <u>Recommended:</u> Additional moisture protection with a second plastic bag and desiccant cartridge.	In original transportation box and original packing.
<b>Medium term</b> max. 2 years	Not recommended	In original transportation box and original packing.
<b>Long term</b>	Not recommended	- <u>Lower part of the bushing in a storage container, filled with oil or dry nitrogen.</u> or: In original transportation box and original packing. Only in dry rooms, temperature as constant as possible. <u>The desiccant cartridge should be checked regularly. The bushing must be fully wrapped into laminated aluminium foil (PETP/Alu/PE).</u> Quantity of desiccant 2½TME/m <sup>2</sup> for moderate climate 25 TME/m <sup>2</sup> for extreme climate TME/ m <sup>2</sup> : Desiccant unit per m <sup>2</sup> of the barrier surface

**Note: Bushings stored in special storage containers can be used immediately even after long-term storage without any further testing.**

### 3.1 Proceedings after inexpert storage

It is possible that humidity diffuses into the insulation core.

If you are suspicious whether the storage conditions meet the requirements in above table or not, you can verify it by a capacitance and power factor  $\tan \delta$  measurement at about 10 kV test voltage applied to the main conductor. If the power factor deviates too much from the original factory test results or if you are uncertain about the conditions, please contact the manufacturer for further information. Please inform about the prevailing temperature at the time of measurement.







**CAUTION**

**DO NOT OPERATE THE BUSHING WITH REMOVED CAP FROM MEASURING TAP, AS IT WILL RESULT IN CORROSION OF THE GROUNDING CONTACT, DAMAGE THE BUSHING AND CAUSE ELECTRICAL FAILURE OF THE BUSHING AND THE TRANSFORMER.**

**THE VOLTAGE ON THE MEASURING TAP MUST NEVER EXCEED 1,5 kV WHEN MEASURING POWER FACTOR. FAILURE TO FOLLOW THESE GUIDELINES COULD RESULT IN SEVERE PERSONAL INJURY, DEATH OR PROPERTY DAMAGE**

## **5 Maintenance, repair, disposal**

### **5.1 Maintenance**

Before getting the bushing into service, carry out a measurement of dissipation factor  $\tan\delta$  and capacity  $C_1$  between high voltage conductor and test tap at voltage up to 10kV to have a reference for later checks.

Apart from periodical cleaning in case of heavy pollution, and measurement every 5 years of  $C_1$  and relevant dissipation factor, the bushings do not need any maintenance.

The old bushings are suitable for service if, regarding the values of reception test, there are no increase higher than (note: values only indicatives):

- 1% for the capacitance  $C_1$  (to assure that there isn't a perforation between two layers)
- 30% for  $\tan\delta$  of capacitance  $C_1$ .
- 100% for  $\tan\delta$  of capacitance  $C_0$ .

An increase of the last value means a de-rating of the dielectric characteristic of the external layers of the resin impregnated paper.

### **5.2 Spare parts**


When ordering spare parts always indicate serial number and type of bushing mentioned on the name plate.

### **5.3 Repair**

Repair can only be performed according to manufacturer's instructions. For this, please have serial number, type of bushing and exact description of damage ready.



## 5.4 Safety information



## 5.5 Disposal

After reaching the end of lifetime, this product must be disposed correctly according to local laws and regulations.


All the contained substances and material should be recycled separately. The product as a whole and its individual parts do not contain any toxins.

No breathing-, no skin protection nor any special precautions are required. Apply the common and appropriate safety standards to prevent working accidents. In case of uncertainties please contact the manufacturer for advanced information and instructions.

## 5.6 NAME PLATE

Each bushing is provided of a name plate, with serial number and all the electrical data, in accordance with the prescription of IEC Standards.

The nameplate (fig. 2) is fixed on the flange by nails. On the name plate the following information are indicated:



The month is indicated by a code, as follows:

A = January	L = July
B = February	M = August
C = March	P = September
D = April	R = October
E = May	S = November
H = June	T = December

**Fig. 2**



## **6 Appendix**

**6.1 General design drawing**


**6.2 Handling of the bushing**

**6.3 Conductor assembly**

**6.4 Instruction for operation of measuring tap**




## 6.1 General design PSR Oil-Air Bushing







## 6.2 Handling of the bushing

- Packing and delivery Condition






- Lifting out and erection in position





### 6.3 Conductor assembly



The stud (1) must be pulled through the central tube by using a rope and a M8 ring screw. Thread at the top of the stud is available to apply the screw. **(avoid damage the thread)**

**Note:** make sure that you not damage the silver plating of the stud.


The stud will be fixed with the two half rings (2) and finally locked with the ring nut (3). The ring nut has to be closed hand tight. Then close the Top terminal by moving by hand into the stud (1). Make sure that it is running smooth. No big force or additional tools are necessary. Mount the screws (5) by using the foreseen LOCTITE and fix them crosswise by using the right tool. Mount the de-aeration screw (6) and lock it with the foreseen tool.

**Note:** Make sure that the de-aeration screw (6) is always mounted and locked.



## 6.4 Measuring Tap Welded contact type

<b>1</b>	<b>GENERAL DESIGN</b>	<b>15</b>
<b>2</b>	<b>PURPOSE</b>	<b>1</b>
<b>3</b>	<b>CONNECTION</b>	<b>2</b>
	3.1 Capacitance- and power factor measurements	2
<b>4</b>	<b>INSULATION TESTS</b>	<b>2</b>
<b>5</b>	<b>APPENDICES</b>	<b>2</b>





## 1 GENERAL DESIGN

The test tap is an accessory for capacitance graded bushings which makes it possible to access a control layer insulated from the flange from the outside and thus to divide the total capacitance of the bushing into 2 sub-capacitances  $C_1$  (high-voltage conductor - test layer) and  $C_2$  (test layer - flange).

The test tap is so designed, that a connection between the test layer and the flange is automatically established, through the grounding cap, when the test tap is not in use. This connection can only be opened by removing the grounding cap. For normal operation of the bushing the test tap must always be closed with the supplied grounding cap.

## 2 PURPOSE

The normal purpose of the test tap is to measure the capacitance  $C_1$  and its loss factor  $\tan\delta$ . The most common test circuit for this purpose is shown in the enclosed drawing.

The test tap can also be used to carry out a permanent voltage measurement or partial discharge monitoring. The maximum permissible permanent voltage between the test layer and the flange is 1.5 kV. Depending on the rated voltage and the capacitance of the bushing the test tap can be loaded with 5 to 10 kV. An impedance must always be connected in parallel to  $C_2$  to limit the voltage to  $\leq 1.5$  kV. This impedance is mostly a capacitance  $C_z$  that must have a minimum value:

$$U = \frac{U_N / \sqrt{3}}{a^2 + b^2} \cdot \sqrt{a^2 + b^2} \leq 1,5kV$$

The values of  $C_1$  and  $C_2$  can be taken from the test report for the particular bushing. To get a specified voltage  $U$ , it is necessary to use a capacitance  $C_z$ :

$$C_z = C_1 \cdot \left( \frac{U_N}{\sqrt{3} \cdot U} - 1 \right) - C_2 \geq C_{z\min}$$

To take reactive power from the test tap an Ohmic resistor must be put in parallel to  $C_2$ . The possible power  $P$  that can be taken from the test tap is:

$$P = \frac{(U_N / \sqrt{3})^2}{R_z} \cdot \frac{1}{a^2 + b^2} \quad \text{with} \quad a = 1 + \frac{C_2}{C_1} \quad b = \frac{1}{\omega C_1 \cdot R_z}$$

However it is a requirement that  $U$  remains  $\leq 1,5$  kV. This can be checked with:

$$U = \frac{U_N / \sqrt{3}}{a^2 + b^2} \cdot \sqrt{a^2 + b^2} \leq 1,5kV$$





#### CAUTION

Without additional external impedance, the voltage resulting by  $C_1$  and  $C_2$  is always higher than 1.5 kV at the test tap. With live bushings either the test tap must be connected conductively with the flange or the divider voltage produced must be limited to 1.5 kV by adding impedance. **Otherwise the bushing will be damaged and could explode!**

The obtainable measurement accuracy depends on the changes of  $C_1$  and  $C_2$  as a function of the temperature of the bushing. It can be calculated within < 5%.

### 3 CONNECTION

#### 3.1 Capacitance- and power factor measurements

After applying a plug coupler, the connection to a measuring bridge can be performed with a wire with standard plugs.

### 4 INSULATION TESTS

The insulation strength of the test tap of each bushing is checked with 3 kV for 1 min. by the routine test of the bushing acc. to IEC 60137.


### 5 APPENDICES

#### 5.1 Drawing measuring tap

#### 5.2 Drawing measuring circuit



### 5.1 Drawing measuring tap



**CAUTION**

**The brass Cap must be closed after measurements. Otherwise the bushing will be damaged and could explode!**

Upon request, on the bushing's flange, it can be mounted another type of PF tap (fig. 20), according to the French Standard NFC 52062.





Fig. 20  
Power Factor tap NFC (on request)



5.2 Measuring circuit



- ① Bushing
  - C1: Capacity high voltage lead- test tap
  - C2: Capacity test tap- flange
- ② Standard capacitor  $C_N$
- ③ Schering bridge
 

$R_3$	} Bridge components
$R_4$	
$C_4$	
- N: Null indicator